




Fitting Guide for the County, Estate and Equine Estate Catch

Set the gate to open both ways by hanging it between the posts. Examples of hinges to hang the gate on can be found on our accessory page.



If fitting the County Catch leave about a 50mm gap between the gate and gate post. If fitting the Estate or Equine Estate Catch leave about a 40mm gap between the gate and gate post.



If the gate is to be used by non-riding traffic, then the catch should be fitted approximately one metre above the ground. If the gate is to be ridden through, it should be fitted at the top of the gate so that it can be easily reached from horseback.

Use four M10 x 50 stainless steel coach screws to ensure a rust free set up. These can be found on our accessory page.



When you have decided the best position for your catch, fit it to the centre of the gate post



For more information on the fitting of catches or accessories please ring 07768 748494